

Using the X-Series Command Line Interface (CLI)

CLI Guide | X-Series Appliances | v8.2.x

Forcepoint™ X-Series appliances are configured and maintained through a command line interface (CLI).

- The CLI is a text-based user interface for configuring, monitoring, and troubleshooting the appliance.
- The CLI allows you to write scripts to execute configuration changes and perform updates across multiple blades more efficiently.

This guide describes the syntax and usage of each CLI command, including:

- [Conventions](#), page 1
- [System configuration](#), page 10
- [Maintenance and support](#), page 24

X-Series [Copyrights and Trademarks](#) statements are included in this document.

Conventions

CLI Guide | X-Series Appliances | v8.2.x

Administrators who are new to the appliance CLI may benefit from these quick summaries:

- [Logon and authentication](#), page 2
- [CLI modes \(context\) and account privileges](#), page 3
- [Command syntax](#), page 9
- [Help for CLI commands](#), page 9

Logon and authentication

After the X10G hardware is set up, you will execute the **firstboot** wizard through the CMC to boot each blade appliance into the correct security mode (Web or Email) and policy mode (for Web appliances), and to give each blade a name and IP address.

See the [X10G Getting Started Guide](#) for full setup details.



Important

Make sure that Microsoft SQL Server is installed and running, and that you have database credentials ready.

To support TRITON AP-WEB, the network needs one—and only one—policy source machine to manage policy and configuration data for your deployment. That server must be set up first. This can be a server that is off-chassis (recommended) or the blade in SLOT-1.

The [Getting Started Guide](#) provides important assistance with off-chassis policy source setup.

When you are ready to start booting the blades:

1. Power on a blade.
2. Log on to the CMC.
 - a. Enter the IP address of the CMC into a browser that has connectivity to the network the chassis is on.

```
http://<CMC_IP_address>
```

Replace *<CMC_IP_address>* with the address assigned to the CMC during initial configuration of the chassis.
 - b. If there is a security warning, continue to the address and enter the CMC logon credentials.
3. On the home screen, select SLOT-*N* from the list on the left, where “N” is the slot of the blade being configured. If the policy source machine will be a blade server, configure it first in SLOT-1.
4. Select **Launch Remote Console** on the upper right. A new command-line window opens.

If it fails to open, look in the blade iDRAC window (launched when you attempted to open the console), and:

 - a. Go to **Overview > Server > Virtual Console**.
 - b. Change the **Plug-in Type** from **Native** to **Java** or **Java** to **Native**.
 - c. Click **Apply** and then **Launch Virtual Console** (upper left).
5. In the console, accept the subscription agreement if prompted. You are now entering the firstboot wizard.

Choose initialization settings such as the appliance name, IP address, time and date, and, for web protection products, the policy mode.

You have an opportunity to change these settings before you exit firstboot. All except one setting can be changed later, through the CLI.



Important

After firstboot has been run to completion, you cannot change the security mode or policy mode without re-imaging the blade.

In addition, if you assign a default VLAN ID during firstboot, then later want to configure the blade to be VLAN-unaware, you must re-image.

At the conclusion of firstboot, you are logged on as **admin** automatically. Your logon session is timed out after 15 minutes, unless you log out prior to that.

From that point forward, the account name and password are required for logging on.

CLI modes (context) and account privileges



Tip

Be sure to enable CLI remote access if you plan to use PuTTY or other remote tool to access the CLI.

```
set access ssh --status on
```

By default, only the **admin** account is enabled on each blade. This is the account password that you set during the firstboot process.

Three working contexts are supported by the Command Line Interface (CLI) and are available to every person logged on as admin.

Context Name	Description
view	The default context. Used for displaying status and settings.
config	The context required for changing settings and enabling/disabling options.
diagnose	The context used to perform troubleshooting. It provides support for system and network test commands.

Immediately after logon, an admin is always in the **view** context.

To move to the **diagnose** context, enter **diagnose** on the command line.

To move from **view** to the **config** context, enter **config** on the command line. The **admin** password is required for this context switch.

- Only one person logged in as **admin** can be working in **config** context at a time.
- If needed, a person logged in as **admin** who is working in the **view** context can use the following command to immediately bump the admin who is working in the **config** context:

```
clear session --config
```

This moves the administrator who had been working in **config** context back into the **view** context.

A person logged in as **admin** can optionally enable two accounts: an **audit** account for colleagues who need to view settings, and a technical support account for use by a Forcepoint technician (**websense-ts**).

To summarize the differences between the admin and audit accounts:

- The **admin** account has full privileges in the **view**, **config**, and **diagnose** contexts.
- The **audit** account can work only in the **view** context and can use only **show** and **exit** commands.

Basic account management

A person who is logged in as **admin** can view, enable, and disable the **audit** account status and can change the password for the **admin** and **audit** accounts.

Configure accounts

Action and Syntax	Details
<pre>show account admin</pre>	
<p>Change the password for the admin account.</p> <pre>set account admin --password <password></pre>	<p>You must know the current admin password to make this change.</p> <p>The admin password is first set when you run the firstboot script.</p> <p>The password must be 8 to 15 character in length and it must include:</p> <ul style="list-style-type: none"> • At least one uppercase character • At least one lowercase character • At least one number • At least one character in the set: (! # % & ' () * + , - . / ; < = > ? @ [] ^ _ { } ~ <p>Exclude all of the following:</p> <ul style="list-style-type: none"> • The special characters: space \$: ` \ " • Not repeat the previous 3 passwords for the account • The device's hostname • The user name of any appliance service account (admin, root, websense-ts, audit) • Common appliance-related names, such as appliance, filtering, TRITON, AP-WEB, AP-EMAIL, ContentGateway, PolicyBroker, PolicyDatabase, and similar
<p>See if the audit account is enabled or disabled.</p> <pre>show account audit --status</pre>	<p>The audit account is disabled by default.</p>

Action and Syntax	Details
<p>Enable or disable the audit account.</p> <pre>set account audit --status <on off></pre> <p>Set or change the audit account password.</p> <pre>set account audit --password <password></pre>	<p>The --status and --password parameters cannot be used at the same time.</p> <p>The password must be 8 to 15 character in length and it must include:</p> <ul style="list-style-type: none"> ● At least one uppercase character ● At least one lowercase character ● At least one number ● At least one character in the set: (! # % & ' () * + , - . / ; < = > ? @ [] ^ _ { } ~ <p>Exclude all of the following:</p> <ul style="list-style-type: none"> ● The special characters: space \$: ` \ " ● Not repeat the previous 3 passwords for the account ● The device's hostname ● The user name of any appliance service account (admin, root, websense-ts, audit) ● Common appliance-related names, such as appliance, filtering, TRITON, AP-WEB, AP-EMAIL, ContentGateway, PolicyBroker, PolicyDatabase, and similar
<p>Enable or disable remote CLI access via SSH.</p> <pre>set access ssh --status <on off></pre>	<p>SSH status is enabled or disabled for all active accounts.</p>
<p>Display whether remote CLI access via SSH is enabled or disabled.</p> <pre>show access ssh --status</pre>	
<p>Display the admin account email address.</p> <pre>show account email</pre>	
<p>Define an email address to use for admin account password recovery.</p> <pre>set account email --address <address></pre>	<p>A temporary password is sent to this email address when you request automated password recovery help.</p> <p>You must also define an SMTP server. (See next command.)</p> <p>Technical Support can also manually issue a temporary password if you provide the security code you see in the appliance iDRAC console.</p>
<p>Display the SMTP server settings used with the admin email address to facilitate password recovery.</p> <pre>show account smtp</pre>	<p>Displays:</p> <ul style="list-style-type: none"> ● Server IP address or hostname ● Server port ● Server user name ● Server password

Action and Syntax	Details
<p>Define an SMTP server for use during admin account password recovery.</p> <pre>set account smtp --host <location> --port <port> --user <name></pre>	<p>Password recovery requires you to define:</p> <ol style="list-style-type: none"> 1. An SMTP server 2. A valid email address to receive a temporary password <p>The host location can be either the SMTP server's IPv4 address or its hostname.</p> <p>The SMTP port is optional (set to 25, by default).</p> <p>The user is the account to use to connect to the SMTP server</p>
<p>For admin account password recovery, enter Ctrl+P.</p>	<p>If you have lost or forgotten your admin password, you can either:</p> <ul style="list-style-type: none"> • Have a temporary password sent to the email address configured on the blade. • Contact Technical Support to receive a temporary password by providing the security code displayed on the appliance iDRAC console. <p>Use the temporary password to log on to the blade and enter a new password within 1 hour. If you are not able to set a new password within the hour, you'll need to start the password recovery process over, by obtaining a new temporary password.</p> <p>The password must be at least 8 characters but less than 15 characters. The password must contain at least one letter and one number.</p>
<p>Delete the password recovery email address.</p> <pre>delete account email</pre>	
<p>Delete SMTP settings.</p> <pre>delete account smtp</pre>	

Action and Syntax	Details
<p>Show Technical Support account access or activity history.</p> <pre>show account websense-ts --status show account websense-ts --history</pre>	<p>The --status and --history parameters cannot be used at the same time.</p> <p>The activity history includes both local and remote access via the websense-ts account.</p>
<p>Enable or disable access for Technical Support.</p> <pre>set account websense-ts --status <on off></pre>	<p>A temporary passcode is generated when you enable this access. Technical Support retrieves the passcode from a special URL.</p> <p>To allow Technical Support remote access, SSH access must also be enabled via the “set access ssh --status on” command</p> <p>When a technician uses the websense-ts account, the session ends automatically after 15 minutes of inactivity.</p> <p>View the logon history of the websense-ts account with:</p> <pre>show account websense-ts --history</pre>

Session management

Action and Syntax	Details
<p>Enter the appliance CLI config context.</p> <pre>config</pre>	<p>Audit accounts do not have access to this context. The admin password is required.</p>
<p>Show connection information for active CLI sessions.</p> <pre>show session</pre>	
<p>End a config mode session immediately.</p> <pre>clear session --config</pre>	<p>Ends the session for whichever admin is in config mode, and allows another admin to enter config mode.</p>
<p>Exit the current config context.</p> <pre>exit</pre>	<p>If you are working in the config or diagnose contexts, you return to the view context.</p> <p>If you are in the view context, your session ends and you exit the appliance CLI.</p>

Command syntax

The CLI syntax follows this format:

```
Command + Option + Parameter
```

Typically, verbs such as **show**, **set**, and **save** are used to view status or statistics, to change the configuration, and to initiate actions.

For example:

```
# set system clock --date <yyyy/mm/dd>
```

In this example:

- **set system** is the command.
- **clock** is the option.
- **--date** is the parameter, which takes a value in the format yyyy/mm/dd.

Some commands have options and parameters, while others do not. Please refer to [Help for CLI commands, page 9](#), for more details.

Help for CLI commands

Assistance is built into the CLI.

Use the **help** command to access information at any level.

```
# help
# help show
# help show log
```

Use the special character (**?** the question mark) to display help for the current command path without pressing **Enter** and without losing the current input.

```
# ?
# show ?
# show system ?
```

System configuration

CLI Guide | X-Series Appliances | v8.2.x

Use the System Configuration commands of the security blade CLI to view, set, or change:

- [Time and date](#), page 10
- [Host name and description](#), page 12
- [Filestore definition and file save commands](#), page 13
- [Appliance interface configuration](#), page 14
- [Static routes](#), page 16.
- [SNMP monitoring \(polling\)](#), page 18
- [SNMP traps and queries](#), page 20

Time and date

Action and Syntax	Details
View the system date and time. <code>show system clock</code>	The time and date format is: yyyymmdd hh:mm:ss
Set system time and date manually. <code>set system clock</code> --date <yyyymmdd> --time <hh:mm:ss>	Stop all TRITON services before changing the time. Then, set the time and make certain that the time is consistent across all servers running TRITON services. Finally, start appliance services. If you do not stop the services first, client updates and policy changes entered after the time reset are not saved. Note that instead of setting the time manually, you can synchronize with a Network Time Protocol (NTP) server. See “set system ntp” below.
View the configured time zone. <code>show system timezone</code>	
View supported timezone formats. <code>show system timezone-list</code>	
Set the timezone for this security blade. <code>set system timezone</code> --zone <zone_string>	GMT (Greenwich Mean Time), the default, is also known as UTC (Universal Time, Coordinated). Other time zones are calculated by adding or subtracting from GMT. GMT is sometimes chosen to provide a common time stamp for geographically distributed systems.

Action and Syntax	Details
View the configured NTP servers. <pre>show system ntp</pre>	
Configure timezone synchronization with up to 3 NTP servers. <pre>set system ntp {--status <on off> --server <server1>, <server2>,<server3>}</pre>	<p>To synchronize with a Network Time Protocol (NTP) server (www.ntp.org), set the status to “on” and enter the address of a primary NTP server. The secondary and tertiary servers are optional.</p> <p>If you synchronize the system clock with an NTP server, NTP protocol packets and their response packets must be allowed on any firewall or NAT device between a security blade and the NTP server. Ensure that you have outbound connectivity to the NTP servers. Add a firewall rule that allows outbound traffic to UDP port 123 for the NTP server.</p> <p>If interface P1 on a security blade is not connected to the Internet, then you must provide a way for interface P1 to reach an NTP server. One solution is to install an NTP server on the local network where interface P1 can reach it.</p>

Host name and description

Action and Syntax	Details
<p>View the security blade hostname and description.</p> <pre>show system host</pre>	<p>These values are set initially during the firstboot wizard.</p>
<p>Change the hostname and description for the security blade.</p> <pre>set system host --name <name> --description "<description>"</pre>	<p>Name: The hostname may be 1 - 60 characters long.</p> <ul style="list-style-type: none"> • The first character must be a letter. • Other characters can be letters, numbers, dashes, or periods. • The name cannot end with a period. • The name cannot have 2 periods in a row. <p>For Web mode blades where Content Gateway will be configured to perform Integrated Windows Authentication (IWA), the hostname cannot exceed 11 characters, excluding the domain name.</p> <p>In addition, if the hostname is changed after the blade has been joined to a domain, IWA will immediately stop working and will not work again until the domain is unjoined and then re-joined with the new hostname.</p> <p>For more information, see the “Integrated Windows Authentication” topic in the Content Gateway Manager Help.</p> <p>Description (<i>optional</i>): A unique appliance description to help you identify and manage the system.</p> <ul style="list-style-type: none"> • Must be in quotation marks • May contain up to 100 characters

Filestore definition and file save commands

Action and Syntax	Details
Display all filestore aliases. <pre>show filestore</pre>	A filestore is a remote storage location that you define for storing backup and configuration files.
Define a remote location to host backup and configuration files. <pre>set filestore --alias <name> --type <ftp samba tftp> --host <ip_address> --path <share_directory> [--user <user_name>] [--port <port>]</pre>	<ul style="list-style-type: none"> ● --alias: Provide a unique name for the remote storage location. The alias must be between 1 and 60 characters and begin with a letter. It may contain letters, numbers, periods, and hyphens, but may not contain 2 consecutive periods, nor end with a period. ● --type: Specify the protocol to use to connect to the filestore (FTP, Samba, or TFTP). ● -- host: Provide the IP address of the machine hosting the filestore. ● --path: Give the directory path to the shared location on the remote server. ● --user (optional): Provide a user account with full permissions to the filestore. ● --port (optional): Specify a port to use to connect to the filestore. Example with Samba. Note the “--user” name format. <pre>set filestore --alias X10Gfstore --type samba --host 10.123.48.70 --path X10GFiles --user domain_name/user_name</pre> Incorrectly formed “--user” argument may result in misleading error messages.
Delete one or more filestore aliases. <pre>delete filestore --alias <filestore_alias></pre>	You can specify a comma-separated list of filestore aliases: <pre>delete filestore --alias ftp-fs1,samba-fs5</pre>
Save the appliance MIB file to the specified location. <pre>save mibfile --location <filestore_alias></pre>	Saves the MIB file to a remote storage location defined by the “set filestore” command.
Summarize configuration data and save it to a specified location. <pre>save configsummary --location <filestore_alias></pre>	Saves your configuration data to a remote storage location defined by the “set filestore” command. May be requested by Technical Support for analyzing unexpected behavior.

Action and Syntax	Details
<p>Save SNMP trap events settings for editing or later use.</p> <pre>save trap --location <filestore_alias> [--default]</pre>	<p>Saves default trap settings for editing. If “--default” is not specified, saves current trap settings.</p>
<p>Zip a log file and save it to a remote filestore.</p> <pre>save log --module <all app> --type <file_type> --location <filestore_alias></pre>	<p>Specify which module logs to save, which type of logs to save, and where to save the file.</p> <p>The module options are all or app, both of which currently save logs for all modules.</p> <p>The log types are all, system, or audit.</p>

Appliance interface configuration

Action and Syntax	Details
<p>Display the current network interface configuration.</p> <pre>show interface</pre>	
<p>Configure appliance interface in IPv4 settings.</p> <pre>set interface ipv4 --interface <p1 p2> --ip <ipv4_address> --mask <ipv4_netmask> --gateway <ipv4_address></pre>	<p>The interface name must be p1 or p2.</p> <p>IP address, netmask, and gateway definitions must use IPv4 format.</p>
<p><i>(Email only)</i> Configure appliance virtual IP address settings.</p> <pre>set interface ipv4 --interface <p1 p2> --vip <virtual_ip_address></pre>	<p>Specify a single virtual IPv4 address.</p> <p>You can assign up to 10 virtual IP addresses to an interface, entered one at a time.</p>
<p><i>(Web only)</i> Enable or disable IPv6 support on an appliance.</p> <pre>set interface ipv6 --status <on off></pre>	
<p><i>(Web only)</i> Configure appliance interface in IPv6 settings.</p> <pre>set interface ipv6 --interface <p1 p2> --ip <ipv6_address> --prefixlen <integer> --gateway <ipv6_address></pre>	<p>The interface name must be p1 or p2.</p> <p>IP address and gateway definitions must use IPv6 format.</p> <p>The prefixlen parameter sets the prefix length of the IPv6 address. It must be an integer between 1 and 128.</p>

Action and Syntax	Details
Configure appliance DNS settings. <pre>set interface dns --dns1 <ip_address> [--dns2 <ip_address>] [--dns3 <ip_address>]</pre>	Enter the IP address of the primary domain name server. You can optionally also specify a second and third DNS server. For Email appliances, IP addresses must be entered in IPv4 format only. Web appliances support IPv4 or IPv6 format.
Enable or disable optional interface P2. <pre>set interface p2 --status <on off></pre>	Determines whether the interface is enabled (on) or disabled (off).
Configure appliance VLAN settings. <pre>set interface vlan --interface <p1 p2> --vid <integer></pre>	Assign a VLAN ID to an interface. The VLAN ID must be an integer in the range 2 - 4094. In order for blades to receive VLAN traffic, the A1 and A2 switches must be configured for VLAN support. See the Switch Configuration Guide for details.

Appliance vswitch configuration

Action and Syntax	Details
Show the virtual switch STP bridge priority setting. <pre>show vswitch</pre>	Output: <pre>stp: priority : <stp bridge value></pre>
Set the virtual switch STP bridge priority value. <pre>set vswitch stp --priority <4096-61440></pre>	Priority: An integer in the range 4096-61440. For an explanation of Spanning Tree Protocol bridge priorities, including how the root is determined, see any quality text on layer 2 switching.

Static routes

Action and Syntax	Details
Display the list of configured static IPv4 routes. <pre>show route</pre>	
<i>(Web only)</i> Display the list of configured static IPv6 routes. <pre>show route6</pre>	
Add a static route in IPv4 format. <pre>set route --dest <ipv4_address> --interface <p1 p2> --mask <ipv4_netmask> --gateway <ipv4_address></pre>	Destination IP address must be in IPv4 format (okay to specify subnet instead). The interface name must be p1 or p2. Netmask must be in IPv4 format and must be the subnet mask of the IP address. Gateway (next hop) must be in IPv4 format.
<i>(Web only)</i> Add a static route in IPv6 format. <pre>set route6 --dest <ipv6_address> --interface <p1 p2> --prefixlen <integer> --gateway <ipv6_address></pre>	The interface name must be p1 or p2. IP address and gateway definitions must use IPv6 format. The prefixlen parameter sets the prefix length of the IPv6 address. It must be an integer between 1 and 128.
Delete a single IPv4 static route. <pre>delete route --dest <ip_address> --mask <ipv4_netmask> [--interface <p1 p2>] [--gateway <ip_address>]</pre>	To delete multiple IPv4 routes in a batch, use the “load route” command (described later in this table).
<i>(Web only)</i> Delete a single IPv6 static route. <pre>delete route6 --dest <ipv6_address> --prefixlen <integer> [--interface <p1 p2>] [--gateway <ipv6_address>]</pre>	To delete multiple IPv6 routes in a batch, use the “load route6” command (described later in this table).
Export IPv4 static routes. <pre>save route --location <filestore_alias></pre>	Saves IPv4 static routes to a remote storage location defined by the “set filestore” command.
<i>(Web only)</i> Export IPv6 static routes. <pre>save route6 --location <filestore_alias></pre>	Saves IPv6 static routes to a remote storage location defined by the “set filestore” command.

Action and Syntax	Details
<p>Add or delete one or more IPv4 static route definitions via a text file.</p> <pre>load route --file <file_name> --location <filestore_alias> --action <add del></pre>	<p>The system can handle a maximum of 5000 routes. Each line in the file defines one route.</p> <p>The line format is:</p> <pre><destination_address> <netmask> <gateway> <p1 p2></pre> <p>A blank space separates parameters on a single line.</p> <p>The following characters serve as separators between lines (individual routes):</p> <pre>\r\n</pre> <p>Use the --action parameter to specify whether to add or delete the routes in the file.</p>
<p><i>(Web only)</i> Add or delete one or more IPv6 static route definitions via a text file.</p> <pre>load route6 --file <file_name> --location <filestore_alias> --action <add del></pre>	<p>The system can handle a maximum of 5000 routes. Each line in the file defines one route.</p> <p>The line format is:</p> <pre><destination_address> <prefix_length> <gateway> <p1 p2></pre> <p>A blank space separates parameters on a single line.</p> <p>The following characters serve as separators between lines (individual routes):</p> <pre>\r\n</pre> <p>Use the --action parameter to specify whether to add or delete the routes in the file.</p>

Appliance status

Action and Syntax	Details
<p>Show current CPU usage, refreshed every 4 seconds.</p> <pre>show cpu</pre>	<p>Press Ctrl+C to quit.</p>
<p>Show system memory usage, refreshed every 4 seconds.</p> <pre>show mem</pre>	<p>Press Ctrl+C to quit.</p>
<p>View disk IO activity for a selected module, refreshed every 4 seconds.</p> <pre>show diskio</pre>	<p>You will be given a choice of modules after you enter the command. The modules vary depending on whether the appliance security mode is Web or Email.</p> <p>Press Ctrl+C to quit.</p>

Action and Syntax	Details
Display disk statistics for all partitions. <pre>show diskspace</pre>	Results are shown in these areas: <ul style="list-style-type: none"> ● disk position ● total space ● used space ● free space ● rate The partitions vary depending on whether the appliance security mode is Web or Email.
Show network traffic statistics. <pre>show bandwidth</pre>	Displays bandwidth statistics for each enabled interface. Includes: <ul style="list-style-type: none"> ● Data (byte) ● Packets ● Packets dropped ● Error ● Rate (Mbps) ● Status Data is refreshed every 5 seconds. Press Ctrl+C to quit.

SNMP monitoring (polling)

Action and Syntax	Details
Show SNMP monitor server information. <pre>show snmp config</pre>	
Enable or disable SNMP monitoring (polling). <pre>set snmp service --status <on off></pre>	SNMP monitor service and SNMP trap settings are independent, but SNMP monitor service must be enabled before you activate the SNMP trap configuration.
Configure SNMP v1 monitoring. <pre>set snmp v1 --community <name></pre>	Community name for the appliance. From 5 to 64 characters long with no spaces. All other ASCII characters can be used.
Configure SNMP v2c monitoring. <pre>set snmp v2c --community <name></pre>	Community name for the appliance. From 5 to 64 characters long with no spaces. All other ASCII characters can be used.

Action and Syntax	Details
Configure SNMP v3 monitoring. <pre>set snmp v3 --securitylevel <level> ...</pre>	There are 3 levels of security available for SNMP v3 monitoring: No authentication or encryption: noAuthNoPriv Authentication only: authNoPriv Authentication and encryption: authPriv See full syntax for each level, immediately below.
Configure SNMP v3 monitoring with no authentication or encryption. <pre>set snmp v3 --securitylevel noAuthNoPriv --user <username></pre>	User specifies the account name to use for SNMP monitoring. Enter a user name between 1 and 15 characters long, with no spaces. Only alphanumeric characters can be used.

Action and Syntax	Details
<p>Configure SNMP v3 monitoring with authentication only.</p> <pre>set snmp v3 --securitylevel authNoPriv --user <username> --authentication <md5 sha></pre>	<p>User is the account name to use for SNMP communication. Enter a user name between 1 and 15 characters long, with no spaces. Only alphanumeric characters can be used.</p> <p>SNMP authentication protocol (md5 or sha) specifies an interactive mode for entering the authentication password.</p> <p>Enter an authentication password between 8 and 64 characters long, with no spaces. All other ASCII characters can be used.</p> <p>Sample password dialog is shown here:</p> <pre>(config)# set snmp v3 --securitylevel authNoPriv --user test --authentication md5 Password: ***** Confirm password: *****</pre>
<p>Configure SNMP v3 monitoring with authentication and encryption.</p> <pre>set snmp v3 --securitylevel authPriv --user <username> --authentication <md5 sha> --encrypt <des aes></pre>	<p>User is the account name to use for SNMP communication. Enter a name between 1 and 15 characters, with no spaces. Only alphanumeric characters can be used.</p> <p>SNMP authentication protocol (md5 or sha) specifies interactive mode for entering password.</p> <p>You are prompted for a password and encryption key. The password must be 1-64 characters, and the key 8-64 characters long, with no spaces. All other ASCII characters can be used.</p> <p>Example:</p> <pre>(config)# set snmp v3 --securitylevel authPriv --authentication sha --encrypt des --user test Password: ***** Confirm password: ***** Encrypt key: ***** Confirm encrypt key: *****</pre>

SNMP traps and queries

Action and Syntax	Details
<p>Display SNMP trap server on/off status and version information.</p> <pre>show trap config</pre>	<p>SNMP monitor service and SNMP trap settings are independent, but SNMP monitor service must be enabled before you activate the SNMP trap configuration.</p>
<p>Display a table of SNMP trap events and settings.</p> <pre>show trap events</pre>	

Action and Syntax	Details
<p>Save SNMP trap events settings for editing or later use.</p> <pre>save trap --location <alias> [--default]</pre>	<p>Saves default trap settings for editing. If “--default” is not specified, saves current trap settings.</p>
<p>Enable or disable SNMP traps.</p> <pre>set trap service --status <on off></pre>	<p>SNMP monitor service and SNMP trap settings are independent, but SNMP monitor service must be enabled to activate the SNMP trap configuration.</p>
<p>Load SNMP trap events configuration from a file.</p> <pre>load trap --location <filestore_alias> --file <name></pre>	<p>Enter the name of a predefined remote filestore alias.</p>
<p>Send a test trap to verify SNMP communication.</p> <pre>test trap event</pre>	
<p>Configure SNMP v1 traps for alerting.</p> <pre>set trap v1 --community <name> --ip <ip_address> --port <port></pre>	<p>Enter a community name, trap server IP address, and port for traps sent by the appliance.</p> <p>The community name must be 5 to 64 characters long, with no spaces. All other ASCII characters can be used.</p>
<p>Configure SNMP v2c traps for alerting.</p> <pre>set trap v2c --community <name> --ip <ip_address> --port <port></pre>	<p>Enter a community name, trap server IP address, and port for traps sent by the appliance.</p> <p>The community name must be 5 to 64 characters long, with no spaces. All other ASCII characters can be used.</p>
<p>Configure SNMP v3 traps for alerting.</p> <pre>set trap v3 --engineid <id> --ip <ip_address> --port <port> --securitylevel <level> ...</pre>	<p>There are 3 levels of security available for SNMP v3 traps:</p> <p>No authentication or encryption: noAuthNoPriv</p> <p>Authentication only: authNoPriv</p> <p>Authentication and encryption: authPriv</p> <p>See full syntax for each security level, immediately below.</p>

Action and Syntax	Details
<p>Configure SNMP v3 traps with no authentication or encryption.</p> <pre>set trap v3 --engineid <id> --ip <ip_address> --port <port> --securitylevel noAuthNoPriv --user <username></pre>	<p>Specify the engine ID, IP address, port, and user name to use for communication with your SNMP manager.</p> <p>The engine ID is a hexadecimal number between 10 and 64 characters long. The number cannot be all 0 or F characters, and the length of the string must be an even number.</p> <p>User is the account name to use for SNMP communication. Enter a name between 1 and 15 characters, with no spaces. Only alphanumeric characters can be used.</p>

Action and Syntax	Details
<p>Configure SNMP v3 traps with authentication only.</p> <pre> set trap v3 --engineid <id> --ip <ip_address> --port <port> --securitylevel authNoPriv --user <username> --authentication <md5 sha> </pre>	<p>Specify the engine ID, IP address, port, and user name to use for communication with your SNMP manager.</p> <p>The engine ID is a hexadecimal number between 10 and 64 characters long. The number cannot be all 0 or F characters, and the length of the string must be an even number.</p> <p>User is the account name to use for SNMP communication. Enter a name with 1-15 alphanumeric characters, with no spaces.</p> <p>Specify the authentication protocol used on the trap server (md5 or sha).</p> <p>You are prompted for a password. Enter a password between 1 and 64 characters, with no spaces. All other ASCII characters are okay.</p> <p>Example:</p> <pre> (config)# set trap v3 --engineid 0x802a0581 --ip 10.17.32.5 --port 162 --securitylevel authNoPriv --authentication sha --user test Password: ***** </pre>
<p>Configure SNMP v3 traps with authentication and encryption.</p> <pre> set trap v3 --engineid <id> --ip <ip_address> --port <port> --securitylevel authPriv --user <username> --authentication <md5 sha> --encrypt <des aes> </pre>	<p>Specify the engine ID, IP address, port, and user name to use for communication with your SNMP manager.</p> <p>The engine ID is a hexadecimal number between 10 and 64 characters long. The number cannot be all 0 or F characters, and the length of the string must be an even number.</p> <p>User is the account name to use for SNMP communication. Enter a name with 1-15 alphanumeric characters, with no spaces.</p> <p>Specify the authentication protocol used on the trap server (md5 or sha), and the SNMP encryption protocol (des or aes).</p> <p>You are prompted for a password and encryption key. The password must be 1-64 characters, and the key 8-64 characters long, with no spaces. All other ASCII characters can be used.</p> <p>Example:</p> <pre> (config)# set trap v3 --engineid 0x00b62000 --ip 10.17.10.8 --port 162 --securitylevel authPriv --authentication sha --encrypt des --user test Password: ***** Encrypt key: ***** </pre>

Maintenance and support

CLI Guide | X-Series Appliances | v8.2.x

Access the following groups of commands below:

- [Starting and stopping services, page 24](#)
- [Module status and version details, page 25](#)
- [Appliance patches and hotfixes, page 25](#)
- [Backup and restore, page 29](#)
- [Collecting a configuration summary for analysis, page 30](#)
- [Log files, page 30](#)

Starting and stopping services

Action and Syntax	Details
<p><i>(Web only)</i> Start Web module or Content Gateway services.</p> <pre>start <web proxy></pre>	<p>The start web command starts all services in the Web module.</p> <p>The start proxy command starts all Content Gateway services.</p>
<p><i>(Email only)</i> Start TRITON AP-EMAIL services.</p> <pre>start email</pre>	
<p><i>(Web only)</i> Stop Web module or Content Gateway services.</p> <pre>stop <web proxy></pre>	<p>The stop web command stops all Web module services.</p> <p>The stop proxy command stops all Content Gateway services.</p>
<p>Stop TRITON AP-EMAIL services.</p> <pre>stop email</pre>	
<p>Shut down the appliance.</p> <pre>shutdown appliance</pre>	
<p>Restart the appliance.</p> <pre>restart appliance</pre>	
<p><i>(Web only)</i> Restart a web protection appliance module.</p> <pre>restart <web proxy></pre>	
<p><i>(Email only)</i> Restart the Email module.</p> <pre>restart email</pre>	

Module status and version details

Action and Syntax	Details
Review status information for the appliance controller (APP) module <code>show appliance</code>	Shows: <ul style="list-style-type: none"> • The full blade model -- X10G or X10G G2. • The blade's position in the chassis • The Security mode (Web or Email) • The software version • The Policy mode, if the Security mode is Web
<i>(Web only)</i> Review status information for the Web module. <code>show web</code>	Shows the version of the Web module and lists whether each component in the module is running or stopped.
<i>(Web only)</i> Review status information for the Content Gateway module. <code>show proxy</code>	Shows the version of Content Gateway, the IP address of the Content Gateway manager, and lists whether Content Gateway and the Content Gateway manager are running or stopped.
<i>(Email only)</i> Review status information for the Email module. <code>show email</code>	Lists whether each component in the module is running or stopped.

Appliance patches and hotfixes

All patches and hotfixes available for X10G blades can be listed from the CLI. There are 2 ways to retrieve patch and hotfix files:

- Download the patch or hotfix file directly from Forcepoint download servers to each blade.
- Log on to your Forcepoint [My Account](#), go to the **Downloads > Hotfixes & Patches** page, download the needed files to a filestore, and then upload the files from the filestore to each blade.

The speed of your Internet connection and the size of the patch will influence which method is more efficient for your environment.

Action and Syntax	Details
View a list of available upgrade patches. <code>show patch --list</code>	Shows both patches available on Forcepoint download servers and patch files currently residing on the appliance.
Display the status of the patch download process. <code>show patch --status</code>	Except when using an express upgrade package, the load process is asynchronous, allowing the administrator to perform other CLI tasks while the download occurs. This command lets the administrator check to see if the download is complete.

Action and Syntax	Details
Display information about applied patches. <pre>show patch --history</pre>	The list shows all patches installed on the appliance.
View a list of available appliance hotfixes. <pre>show hotfix list [--id <hotfix_id>] [--location local] [--module <module>]</pre>	The simple command, with no parameters, shows all hotfixes available for download from Forcepoint servers or residing on the appliance. Note the name and ID of the hotfix file you want to install. <ul style="list-style-type: none"> • If you want to download a hotfix to a remote filestore, you will need the hotfix file name. Download hotfixes from the Forcepoint.com > My Account > Downloads > Hotfixes & Patches page. Select a hotfix to see a detailed description. • If you want to download a hotfix directly to each security blade, you will need the hotfix ID. Parameters can narrow the scope of hotfixes displayed: <ul style="list-style-type: none"> • Use --id to see information about a specific hotfix. • Use --module and specify a module type to see hotfixes for the appliance module (app), Web module (web), Content Gateway module (proxy), or Email Security module (email). • Specify --location local to see hotfixes residing on the appliance.
Display the status of the hotfix download process. <pre>show hotfix load --status</pre>	The load process is asynchronous, allowing the administrator to perform other CLI tasks while the download occurs. This command lets the administrator check to see if the download is complete.
Display the status of the hotfix installation or removal process. <pre>show hotfix install --status show hotfix uninstall --status</pre>	
Show information about applied hotfixes.	The list of hotfixes installed or uninstalled, or that failed to install on the appliance.

Action and Syntax	Details
<p>Select and download patch files, or select, download, and install express upgrade patches.</p> <pre>load patch [--file <name> --location <alias>]</pre>	<p>Use the “load patch” command with no parameters to see a list of patch files and express upgrade packages available on Forcepoint servers.</p> <ul style="list-style-type: none"> • Select a patch file from the list to download it to the appliance, and then use the “install patch” command to start the upgrade. • Select an express upgrade package to download it to the appliance and automatically initiate the upgrade process. <p>Use the “load patch --location <alias>” command to see a list of patch files and express upgrade packages available on a remote filestore. Note that if you change the name of a file in a remote filestore, the file will fail to download.</p> <p>Use the “load patch --file <name>” command to download a specific patch file, rather than selecting it from a list.</p> <p>IMPORTANT: When performing an upgrade, or preparing a remote filestore to support an express upgrade package, always follow the instructions in the X-Series upgrade guide.</p>
<p>Download or upload a hotfix to the appliance.</p> <pre>load hotfix [--id <hotfix_id>] [--file <name>] --location <alias>]</pre>	<p>Specify the hotfix ID to download a hotfix from Forcepoint servers, or specify a hotfix file name and location to upload the hotfix from a remote filestore.</p> <ul style="list-style-type: none"> • Use the “show hotfix --id” command to find the hotfix ID on the download server. • The filestore alias is created with the “set filestore” command. <p>Enter the “load hotfix --location <alias>” command with no file name to select the hotfix from a list of files on the filestore. Note that if you change the name of a hotfix file in a filestore, the option cannot be used.</p>
<p>Install a patch file on the appliance.</p> <pre>install patch [--file <patch_name>]</pre>	<p><patch_name> is the exact name of the patch file.</p> <p>Enter “install patch” without the “--file” parameter to select the patch file from a list of patch files residing on the appliance.</p>
<p>Install a hotfix file on the appliance.</p> <pre>install hotfix [--id <hotfix_id>]</pre>	<p>If no hotfix ID is specified, you can choose from a list of available hotfix files.</p>
<p>Remove a patch file from the appliance.</p> <pre>delete patch --file <patch_name></pre>	<p>This removes patch files that have been transferred to the appliance, but not installed.</p> <p><patch_name> is the exact name of the patch file.</p>

Action and Syntax	Details
Remove a hotfix file from the appliance. <code>delete hotfix</code> <code> [--id <hotfix_id>]</code>	This removes hotfix files that have been transferred to the appliance, but not installed. If no hotfix ID is specified, you can choose from a list of available hotfix files.
Uninstall a hotfix from the appliance. <code>uninstall hotfix</code> <code> [--id <hotfix_id>]</code>	If no hotfix ID is specified, you can choose from a list of installed hotfixes.

Backup and restore

Action and Syntax	Details
<p>Show all available backups in a specified location.</p> <pre>show backup list --location <local alias></pre>	<p>Displays the file name, date, and description of each patch file found in the specified location.</p> <ul style="list-style-type: none"> ● local is the current security blade. ● alias is the filestore alias of a remote storage location.
<p>Display the configured backup schedule.</p> <pre>show backup schedule</pre>	<p>Includes the schedule frequency, the last scheduled backup, the next scheduled backup, and the backup location.</p>
<p>Create a full appliance backup now.</p> <pre>create backup now --location <local alias> [--desc "<description>"]</pre>	<p>You can back up files onto the appliance (local) or onto a remote filestore. You can restore from either location.</p> <p>The optional description of the backup is limited to 18 characters and must be enclosed in single or double quotes (' or ").</p> <p>Each appliance can store up to 20 backup files.</p>
<p>Restore the appliance configuration settings saved in the specified backup file.</p> <pre>restore backup --location <local alias> [--file <file_name>]</pre>	<p>For location, specify a filestore alias or “local” for a local file.</p> <p>Optionally specify the name of the backup file to restore. If you do not specify a name, you can choose a file from a list.</p>
<p>Define a schedule of automatic backups.</p> <pre>create backup schedule --location <local alias> --freq <interval> --day <day_name> --date <month_day> --time <hh:mm></pre>	<p>Backups are full appliance backups, including all installed modules.</p> <p>You can schedule a backup to occur daily, weekly, or monthly, to the appliance (“local”) or to a remote filestore.</p> <p>For the frequency interval, specify daily, weekly, or monthly (required).</p> <p>For all interval options, specify the time of day in 24-hour format (hh:mm). Do not specify seconds.</p> <p>If the interval is weekly, also specify the day of the week: Mon, Tue, Wed, Thu, Fri, Sat, or Sun (case matters).</p> <p>If the interval is monthly, also specify the day of the month (integer from 1-28).</p>
<p>Cancel all scheduled backups.</p> <pre>cancel backup schedule</pre>	
<p>Delete all backup files in a location or a named backup file.</p> <pre>delete backup --files <name all inter></pre>	<p>Takes one of the following values:</p> <ul style="list-style-type: none"> ● name: the name of a specific file ● all: every backup file on the appliance ● inter: interactive mode, which can be used to select files to delete

Collecting a configuration summary for analysis

Action and Syntax	Details
<p>Create a configuration summary file for Technical Support analysis.</p> <pre>save configsummary --location <filestore_alias></pre>	<p>Collects both the appliance configuration and all configurations for the modules running on the appliance.</p> <p>You must choose a remote location that can be shared with Technical Support.</p>

Log files

Action and Syntax	Details
<p>Display a list of log file types.</p> <pre>show log typelist --module <all app></pre>	<p>Specify a specific module whose log file types should be shown.</p> <p>all (default) includes all modules.</p> <p>app includes the entire appliance.</p>
<p>Display the last <i>n</i> lines of the appliance log file.</p> <pre>show log lastline --module app --type <system audit> --line <integer></pre>	
<p>Display data as it is appended to the appliance log file.</p> <pre>show log realtime --filter <string> --type <system audit> --module app</pre>	
<p>Configure how log files are archived.</p> <pre>set log archive --type <system audit> --size <integer string>] --freq <weekly monthly yearly>]</pre>	<p>When a log file reaches the specified maximum size (between 10 MB and 200 MB), or at the specified frequency interval, the file is archived and a new log file is started.</p> <p>The default unit of measurement for --size is bytes. To instead use kilobytes or megabytes, append “k” or “m” to the size. For example:</p> <pre>set log archive --size 50m</pre> <p>Use freq to specify a frequency interval: weekly, monthly, or yearly.</p>

Action and Syntax	Details
Display log file archiving settings. <pre>show log archive --type <system audit></pre>	Determine whether log files are being archived, and if so, what criteria are used to determine when older log data is archived and a new log file is started.
Zip the log file and move it to a remote filestore. <pre>save log --module <all app> --type <all system audit> --location <filestore_alias></pre>	The filestore alias of a remote storage location is defined by the “set filestore” command

Diagnose

Action and Syntax	Details
Displays the kernel ARP table. <pre>arp</pre>	
Netcat (nc) attempts to read and write data across the network to the specified server using the specified protocol. Use netcat for functional tests of components and verification of connectivity. <pre>nc --protocol <tcp udp> --dest <ipv4_addr hostname> --port <port_number></pre>	If you are having problems loading a Web page or are getting a block, this command can help determine the problem. If you see a reset coming from the proxy, you can determine which DOM/module it is coming from. Dest: The IPv4 address or hostname of the server. Port: Port number of the server.
Obtains DNS information for the specified host. <pre>nslookup --host <ipv4_addr hostname> --dns-server <ipv4_address></pre>	Host: The IPv4 address or hostname to be resolved. Dns-server: The IPv4 address or hostname of the DNS server.
Tests connectivity with the specified hostname or IP address. <pre>ping --interface <p1 p2> --dest <ipv4_addr hostname> ping6 --interface <p1 p2> --dest <ipv6_addr hostname></pre>	Ctrl+C to quit. Dest: The IPv4 (ping) or IPv6 (ping6) IP address or hostname with which to test connectivity. Interface: (optional) P1 or P2.

Action and Syntax	Details
<p>Displays information about packets from the specified network interface, for packets matching the specified boolean expression.</p> <pre>tcpdump --location <filestore> --file <filename> --interface <P1 P2> --expression <filter expr></pre>	<p>tcpdump is a packet analyzer. tcpdump intercepts and displays packets being transmitted or received by the specified network interface.</p> <p>The output from tcpdump can help you determine whether all routing is occurring properly, to and from the interface. The output is verbose; it displays the data of each package in both hex and ASCII, and it includes a link-level header on each line.</p> <p>Location: (optional) Save output to a file in this filestore.</p> <p>File: (optional) Name of output file located in the filestore.</p> <p>Interface: (optional) P1 or P2. Interface will display in output as eth0 or eth1.</p> <p>Expression: (optional) A boolean expression used to select the packets of interest.</p> <p>Example 1: To capture all TCP traffic to and from the proxy on port 8080, specify:</p> <pre>"tcp port 8080"</pre> <p>Example 2: To capture all TCP traffic to the site google.com, specify:</p> <pre>"tcp and dst host google.com"</pre> <p>Example 3: To capture all TCP traffic from a specific end-user machine, specify:</p> <pre>"tcp and src host user.example.com"</pre> <p>Note: You can enter a hostname if it is resolvable by a DNS server, but the output uses IP addresses.</p>
<p>Displays the route used by packets to reach the specified destination.</p> <pre>traceroute --dest <ipv4_addr hostname> traceroute6 --dest <ipv6_addr hostname></pre>	<p>If some machines are not receiving policy enforcement, or if traffic is not getting to the appliance, this shows the devices (or hops) that are between the machines that may be blocking access to the host. Use tcpdump to get a packet capture from each device.</p> <p>If you are having latency issues, traceroute can also help identify potential causes.</p> <p>Note: traceroute is of limited usefulness if an IP address is being spoofed.</p>

Action and Syntax	Details
<p>Tests connectivity with the specified URL (file download not supported).</p> <pre>wget --url <url></pre>	<p>Supports non-interactive download of web pages to help diagnose connectivity issues. Use wget, for example, if you have configured the proxy, but cannot access the Web. wget simulates the proxy going out and retrieving content at the specified URL. wget supports HTTP, HTTPS, and FTP.</p>
<p>Tests connectivity between the specified URL and the proxy (file download not supported).</p> <pre>wget-proxy --url <url> --proxy-ip <proxy_ip_addr> --port <proxy_port> --proxy-user <user_name> --proxy-password <password></pre>	<p>Url: The URL of the website to which you want to test connectivity</p> <p>Proxy-ip: The proxy IP address. This is the IP address of the P1 interface on most appliance configurations.</p> <p>Port: The port on which the proxy expects traffic. 8080 is configured for HTTP by default.</p> <p>Proxy-user: The user name of the client, if required for authentication</p> <p>Proxy-password: The password of proxy-user, if required for authentication</p>

Copyrights and Trademarks

Help | X-Series Appliance | v8.2.x

© 1996–2016, Forcepoint LLC

All rights reserved.

10900-A Stonelake Blvd, Quarry Oaks 1, Suite 350, Austin, TX 78759, USA

Published 2016

Printed in the United States of America

This document may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior consent in writing from Forcepoint LLC.

Every effort has been made to ensure the accuracy of this manual. However, Forcepoint LLC, makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability and fitness for a particular purpose. Forcepoint LLC shall not be liable for any error or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples herein. The information in this documentation is subject to change without notice.

Trademarks

Forcepoint and ThreatSeeker are registered trademarks of Forcepoint LLC, in the United States and certain international markets. Forcepoint has numerous other unregistered trademarks in the United States and internationally. All other trademarks are the property of their respective owners.

Microsoft, Internet Explorer, and Active Directory are trademarks or registered trademarks of Microsoft Corporation.

The following is a registered trademark of Novell, Inc., in the United States and other countries: Novell Directory Services.

Adobe, Acrobat, and Acrobat Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Pentium is a registered trademark of Intel Corporation.

Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are the sole property of their respective manufacturers.

Other acknowledgments

Portions of this software may utilize the following copyrighted material, the use of which is hereby acknowledged.

CentOS

Version 6

CentOS-6 EULA

CentOS-6 comes with no guarantees or warranties of any sorts, either written or implied.

The Distribution is released as GPL. Individual packages in the distribution come with their own licenses.

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of

Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files,

plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance

on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING

RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

JRE

Version 1.7.0-76

Oracle Binary Code License Agreement for the Java SE Platform Products and JavaFX

1. DEFINITIONS. "Software" means the software identified above in binary form that you selected for download, install or use (in the version You selected for download, install or use) from Oracle or its authorized licensees, any other machine readable materials (including, but not limited to, libraries, source files, header files, and data files), any updates or error corrections provided by Oracle, and any user manuals, programming guides and other documentation provided to you by Oracle under this Agreement. "General Purpose Desktop Computers and Servers" means computers, including desktop and laptop computers, or servers, used for general computing functions under end user control (such as but not specifically limited to email, general purpose Internet browsing, and office suite productivity tools). The use of Software in systems and solutions that provide dedicated functionality (other than as mentioned above) or designed for use in embedded or function-specific software applications, for example but not limited to: Software embedded in or bundled with industrial control systems, wireless mobile telephones, wireless handheld devices, kiosks, TV/STB, Blu-ray Disc devices, telematics and network control switching equipment, printers and storage management systems, and other related systems are excluded from this definition and not licensed under this Agreement. "Programs" means (a) Java technology applets and applications intended to run on the Java Platform, Standard Edition platform on Java-enabled General Purpose Desktop Computers and Servers; and (b) JavaFX technology applications intended to run on the JavaFX Runtime on JavaFX-enabled General Purpose Desktop Computers and Servers. "Commercial Features" means those features identified in Table 1-1 (Commercial Features In Java SE Product Editions) of the Java SE documentation accessible at <http://www.oracle.com/technetwork/java/javase/documentation/index.html>. "README File" means the README file for the Software accessible at <http://www.oracle.com/technetwork/java/javase/documentation/index.html>.

2. LICENSE TO USE. Subject to the terms and conditions of this Agreement including, but not limited to, the Java Technology Restrictions of the Supplemental License Terms, Oracle grants you a non-exclusive, non-transferable, limited license without license fees to reproduce and use internally the Software complete and unmodified for the sole purpose of running Programs. THE LICENSE SET FORTH IN THIS SECTION 2 DOES NOT EXTEND TO THE COMMERCIAL FEATURES. YOUR RIGHTS AND OBLIGATIONS RELATED TO THE COMMERCIAL FEATURES ARE AS SET FORTH IN THE SUPPLEMENTAL TERMS ALONG WITH ADDITIONAL LICENSES FOR DEVELOPERS AND PUBLISHERS.

3. **RESTRICTIONS.** Software is copyrighted. Title to Software and all associated intellectual property rights is retained by Oracle and/or its licensors. Unless enforcement is prohibited by applicable law, you may not modify, decompile, or reverse engineer Software. You acknowledge that the Software is developed for general use in a variety of information management applications; it is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use the Software in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle disclaims any express or implied warranty of fitness for such uses. No right, title or interest in or to any trademark, service mark, logo or trade name of Oracle or its licensors is granted under this Agreement. Additional restrictions for developers and/or publishers licenses are set forth in the Supplemental License Terms.

4. **DISCLAIMER OF WARRANTY.** THE SOFTWARE IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. ORACLE FURTHER DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT.

5. **LIMITATION OF LIABILITY.** IN NO EVENT SHALL ORACLE BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, OR DAMAGES FOR LOSS OF PROFITS, REVENUE, DATA OR DATA USE, INCURRED BY YOU OR ANY THIRD PARTY, WHETHER IN AN ACTION IN CONTRACT OR TORT, EVEN IF ORACLE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. ORACLE'S ENTIRE LIABILITY FOR DAMAGES HEREUNDER SHALL IN NO EVENT EXCEED ONE THOUSAND DOLLARS (U.S. \$1,000).

6. **TERMINATION.** This Agreement is effective until terminated. You may terminate this Agreement at any time by destroying all copies of Software. This Agreement will terminate immediately without notice from Oracle if you fail to comply with any provision of this Agreement. Either party may terminate this Agreement immediately should any Software become, or in either party's opinion be likely to become, the subject of a claim of infringement of any intellectual property right. Upon termination, you must destroy all copies of Software.

7. **EXPORT REGULATIONS.** You agree that U.S. export control laws and other applicable export and import laws govern your use of the Software, including technical data; additional information can be found on Oracle's Global Trade Compliance web site (<http://www.oracle.com/us/products/export>). You agree that neither the Software nor any direct product thereof will be exported, directly, or indirectly, in violation of these laws, or will be used for any purpose prohibited by these laws including, without limitation, nuclear, chemical, or biological weapons proliferation.

8. **TRADEMARKS AND LOGOS.** You acknowledge and agree as between you and Oracle that Oracle owns the ORACLE and JAVA trademarks and all ORACLE- and JAVA-related trademarks, service marks, logos and other brand designations ("Oracle Marks"), and you agree to comply with the Third Party Usage Guidelines for Oracle Trademarks currently located at <http://www.oracle.com/us/legal/third-party->

trademarks/index.html . Any use you make of the Oracle Marks inures to Oracle's benefit.

9. U.S. GOVERNMENT LICENSE RIGHTS. If Software is being acquired by or on behalf of the U.S. Government or by a U.S. Government prime contractor or subcontractor (at any tier), then the Government's rights in Software and accompanying documentation shall be only those set forth in this Agreement.

10. GOVERNING LAW. This agreement is governed by the substantive and procedural laws of California. You and Oracle agree to submit to the exclusive jurisdiction of, and venue in, the courts of San Francisco, or Santa Clara counties in California in any dispute arising out of or relating to this agreement.

11. SEVERABILITY. If any provision of this Agreement is held to be unenforceable, this Agreement will remain in effect with the provision omitted, unless omission would frustrate the intent of the parties, in which case this Agreement will immediately terminate.

12. INTEGRATION. This Agreement is the entire agreement between you and Oracle relating to its subject matter. It supersedes all prior or contemporaneous oral or written communications, proposals, representations and warranties and prevails over any conflicting or additional terms of any quote, order, acknowledgment, or other communication between the parties relating to its subject matter during the term of this Agreement. No modification of this Agreement will be binding, unless in writing and signed by an authorized representative of each party.

SUPPLEMENTAL LICENSE TERMS

These Supplemental License Terms add to or modify the terms of the Binary Code License Agreement. Capitalized terms not defined in these Supplemental Terms shall have the same meanings ascribed to them in the Binary Code License Agreement. These Supplemental Terms shall supersede any inconsistent or conflicting terms in the Binary Code License Agreement, or in any license contained within the Software.

A. COMMERCIAL FEATURES. You may not use the Commercial Features for running Programs, Java applets or applications in your internal business operations or for any commercial or production purpose, or for any purpose other than as set forth in Sections B, C, D and E of these Supplemental Terms. If You want to use the Commercial Features for any purpose other than as permitted in this Agreement, You must obtain a separate license from Oracle.

B. SOFTWARE INTERNAL USE FOR DEVELOPMENT LICENSE GRANT. Subject to the terms and conditions of this Agreement and restrictions and exceptions set forth in the README File incorporated herein by reference, including, but not limited to the Java Technology Restrictions of these Supplemental Terms, Oracle grants you a non-exclusive, non-transferable, limited license without fees to reproduce internally and use internally the Software complete and unmodified for the purpose of designing, developing, and testing your Programs.

C. LICENSE TO DISTRIBUTE SOFTWARE. Subject to the terms and conditions of this Agreement and restrictions and exceptions set forth in the README File, including, but not limited to the Java Technology Restrictions and Limitations on Redistribution of these Supplemental Terms, Oracle grants you a non-exclusive, non-

transferable, limited license without fees to reproduce and distribute the Software, provided that (i) you distribute the Software complete and unmodified and only bundled as part of, and for the sole purpose of running, your Programs, (ii) the Programs add significant and primary functionality to the Software, (iii) you do not distribute additional software intended to replace any component(s) of the Software, (iv) you do not remove or alter any proprietary legends or notices contained in the Software, (v) you only distribute the Software subject to a license agreement that: (a) is a complete, unmodified reproduction of this Agreement; or (b) protects Oracle's interests consistent with the terms contained in this Agreement and that includes the notice set forth in Section H, and (vi) you agree to defend and indemnify Oracle and its licensors from and against any damages, costs, liabilities, settlement amounts and/or expenses (including attorneys' fees) incurred in connection with any claim, lawsuit or action by any third party that arises or results from the use or distribution of any and all Programs and/or Software. The license set forth in this Section C does not extend to the Software identified in Section G.

D. LICENSE TO DISTRIBUTE REDISTRIBUTABLES. Subject to the terms and conditions of this Agreement and restrictions and exceptions set forth in the README File, including but not limited to the Java Technology Restrictions and Limitations on Redistribution of these Supplemental Terms, Oracle grants you a non-exclusive, non-transferable, limited license without fees to reproduce and distribute those files specifically identified as redistributable in the README File ("Redistributables") provided that: (i) you distribute the Redistributables complete and unmodified, and only bundled as part of Programs, (ii) the Programs add significant and primary functionality to the Redistributables, (iii) you do not distribute additional software intended to supersede any component(s) of the Redistributables (unless otherwise specified in the applicable README File), (iv) you do not remove or alter any proprietary legends or notices contained in or on the Redistributables, (v) you only distribute the Redistributables pursuant to a license agreement that: (a) is a complete, unmodified reproduction of this Agreement; or (b) protects Oracle's interests consistent with the terms contained in the Agreement and includes the notice set forth in Section H, (vi) you agree to defend and indemnify Oracle and its licensors from and against any damages, costs, liabilities, settlement amounts and/or expenses (including attorneys' fees) incurred in connection with any claim, lawsuit or action by any third party that arises or results from the use or distribution of any and all Programs and/or Software. The license set forth in this Section D does not extend to the Software identified in Section G.

Net-snmp

Version 5.5.41

Various copyrights apply to this package, listed in various separate parts below. Please make sure that you read all the parts.

---- Part 1: CMU/UCD copyright notice: (BSD like) ----

Copyright 1989, 1991, 1992 by Carnegie Mellon University Derivative Work - 1996, 1998-2000 Copyright 1996, 1998-2000 The Regents of the University of California

All Rights Reserved

Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appears in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of CMU and The Regents of the University of California not be used in advertising or publicity pertaining to distribution of the software without specific written permission.

CMU AND THE REGENTS OF THE UNIVERSITY OF CALIFORNIA DISCLAIM ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL CMU OR THE REGENTS OF THE UNIVERSITY OF CALIFORNIA BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM THE LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

---- Part 2: Networks Associates Technology, Inc copyright notice (BSD) ----

Copyright (c) 2001-2003, Networks Associates Technology, Inc All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the Networks Associates Technology, Inc nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF

USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 3: Cambridge Broadband Ltd. copyright notice (BSD) ----

Portions of this code are copyright (c) 2001-2003, Cambridge Broadband Ltd. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

- * The name of Cambridge Broadband Ltd. may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 4: Sun Microsystems, Inc. copyright notice (BSD) ----

Copyright © 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Use is subject to license terms below. This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of the Sun Microsystems, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 5: Sparta, Inc copyright notice (BSD) ----

Copyright (c) 2003-2009, Sparta, Inc All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Sparta, Inc nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED

WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 6: Cisco/BUPTNIC copyright notice (BSD) ----

Copyright (c) 2004, Cisco, Inc and Information Network Center of Beijing University of Posts and Telecommunications. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name of Cisco, Inc, Beijing University of Posts and Telecommunications, nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

-- Part 7: Fabasoft R&D Software GmbH & Co KG copyright notice (BSD) --

Copyright (c) Fabasoft R&D Software GmbH & Co KG, 2003
oss@fabasoft.com

Author: Bernhard Penz

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * The name of Fabasoft R&D Software GmbH & Co KG or any of its subsidiaries, brand or product names may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 8: Apple Inc. copyright notice (BSD) -----

Copyright (c) 2007 Apple Inc. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. Neither the name of Apple Inc. ("Apple") nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY APPLE AND ITS CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL APPLE OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

---- Part 9: ScienceLogic, LLC copyright notice (BSD) ----

Copyright (c) 2009, ScienceLogic, LLC All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

* Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

* Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

* Neither the name of ScienceLogic, LLC nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE

USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Nisedit

Version 2.0.3

Copyright (C) 2003-2005 Hector Mauricio Rodriguez Segura

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

Nsis

Version 2.46

Copyright © 1995-2015 Contributors

More detailed copyright information can be found in the individual source code files.

APPLICABLE LICENSES

- * All NSIS source code, plug-ins, documentation, examples, header files and graphics, with the exception of the compression modules and where otherwise noted, are licensed under the zlib/libpng license.
- * The zlib compression module for NSIS is licensed under the zlib/libpng license.
- * The bzip2 compression module for NSIS is licensed under the bzip2 license.
- * The LZMA compression module for NSIS is licensed under the Common Public License version 1.0.

ZLIB/LIBPNG LICENSE

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

BZIP2 LICENSE

This program, "bzip2" and associated library "libbzip2", are copyright (C) 1996-2000 Julian R Seward. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
3. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
4. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Julian Seward, Cambridge, UK.

jseward@acm.org

COMMON PUBLIC LICENSE VERSION 1.0

THE ACCOMPANYING PROGRAM IS PROVIDED UNDER THE TERMS OF THIS COMMON PUBLIC LICENSE ("AGREEMENT"). ANY USE, REPRODUCTION OR DISTRIBUTION OF THE PROGRAM CONSTITUTES RECIPIENT'S ACCEPTANCE OF THIS AGREEMENT.

1. DEFINITIONS

"Contribution" means:

a) in the case of the initial Contributor, the initial code and documentation distributed under this Agreement, and

b) in the case of each subsequent Contributor:

i) changes to the Program, and

ii) additions to the Program;

where such changes and/or additions to the Program originate from and are distributed by that particular Contributor. A Contribution 'originates' from a Contributor if it was added to the Program by such Contributor itself or anyone acting on such Contributor's behalf. Contributions do not include additions to the Program which: (i) are separate modules of software distributed in conjunction with the Program under their own license agreement, and (ii) are not derivative works of the Program.

"Contributor" means any person or entity that distributes the Program.

"Licensed Patents " mean patent claims licensable by a Contributor which are necessarily infringed by the use or sale of its Contribution alone or when combined with the Program.

"Program" means the Contributions distributed in accordance with this Agreement.

"Recipient" means anyone who receives the Program under this Agreement, including all Contributors.

2. GRANT OF RIGHTS

a) Subject to the terms of this Agreement, each Contributor hereby grants Recipient a non-exclusive, worldwide, royalty-free copyright license to reproduce, prepare derivative works of, publicly display, publicly perform, distribute and sublicense the Contribution of such Contributor, if any, and such derivative works, in source code and object code form.

b) Subject to the terms of this Agreement, each Contributor hereby grants Recipient a non-exclusive, worldwide, royalty-free patent license under Licensed Patents to make, use, sell, offer to sell, import and otherwise transfer the Contribution of such Contributor, if any, in source code and object code form. This patent license shall apply to the combination of the Contribution and the Program if, at the time the

Contribution is added by the Contributor, such addition of the Contribution causes such combination to be covered by the Licensed Patents. The patent license shall not apply to any other combinations which include the Contribution. No hardware per se is licensed hereunder.

c) Recipient understands that although each Contributor grants the licenses to its Contributions set forth herein, no assurances are provided by any Contributor that the Program does not infringe the patent or other intellectual property rights of any other entity. Each Contributor disclaims any liability to Recipient for claims brought by any other entity based on infringement of intellectual property rights or otherwise. As a condition to exercising the rights and licenses granted hereunder, each Recipient hereby assumes sole responsibility to secure any other intellectual property rights needed, if any. For example, if a third party patent license is required to allow Recipient to distribute the Program, it is Recipient's responsibility to acquire that license before distributing the Program.

d) Each Contributor represents that to its knowledge it has sufficient copyright rights in its Contribution, if any, to grant the copyright license set forth in this Agreement.

3. REQUIREMENTS

A Contributor may choose to distribute the Program in object code form under its own license agreement, provided that:

a) it complies with the terms and conditions of this Agreement; and

b) its license agreement:

i) effectively disclaims on behalf of all Contributors all warranties and conditions, express and implied, including warranties or conditions of title and non-infringement, and implied warranties or conditions of merchantability and fitness for a particular purpose;

ii) effectively excludes on behalf of all Contributors all liability for damages, including direct, indirect, special, incidental and consequential damages, such as lost profits;

iii) states that any provisions which differ from this Agreement are offered by that Contributor alone and not by any other party; and

iv) states that source code for the Program is available from such Contributor, and informs licensees how to obtain it in a reasonable manner on or through a medium customarily used for software exchange.

When the Program is made available in source code form:

a) it must be made available under this Agreement; and

b) a copy of this Agreement must be included with each copy of the Program.

Contributors may not remove or alter any copyright notices contained within the Program.

Each Contributor must identify itself as the originator of its Contribution, if any, in a manner that reasonably allows subsequent Recipients to identify the originator of the Contribution.

4. COMMERCIAL DISTRIBUTION

Commercial distributors of software may accept certain responsibilities with respect to end users, business partners and the like. While this license is intended to facilitate the commercial use of the Program, the Contributor who includes the Program in a commercial product offering should do so in a manner which does not create potential liability for other Contributors. Therefore, if a Contributor includes the Program in a commercial product offering, such Contributor ("Commercial Contributor") hereby agrees to defend and indemnify every other Contributor ("Indemnified Contributor") against any losses, damages and costs (collectively "Losses") arising from claims, lawsuits and other legal actions brought by a third party against the Indemnified Contributor to the extent caused by the acts or omissions of such Commercial Contributor in connection with its distribution of the Program in a commercial product offering. The obligations in this section do not apply to any claims or Losses relating to any actual or alleged intellectual property infringement. In order to qualify, an Indemnified Contributor must: a) promptly notify the Commercial Contributor in writing of such claim, and b) allow the Commercial Contributor to control, and cooperate with the Commercial Contributor in, the defense and any related settlement negotiations. The Indemnified Contributor may participate in any such claim at its own expense.

For example, a Contributor might include the Program in a commercial product offering, Product X. That Contributor is then a Commercial Contributor. If that Commercial Contributor then makes performance claims, or offers warranties related to Product X, those performance claims and warranties are such Commercial Contributor's responsibility alone. Under this section, the Commercial Contributor would have to defend claims against the other Contributors related to those performance claims and warranties, and if a court requires any other Contributor to pay any damages as a result, the Commercial Contributor must pay those damages.

5. NO WARRANTY

EXCEPT AS EXPRESSLY SET FORTH IN THIS AGREEMENT, THE PROGRAM IS PROVIDED ON AN "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, EITHER EXPRESS OR IMPLIED INCLUDING, WITHOUT LIMITATION, ANY WARRANTIES OR CONDITIONS OF TITLE, NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Each Recipient is solely responsible for determining the appropriateness of using and distributing the Program and assumes all risks associated with its exercise of rights under this Agreement, including but not limited to the risks and costs of program errors, compliance with applicable laws, damage to or loss of data, programs or equipment, and unavailability or interruption of operations.

6. DISCLAIMER OF LIABILITY

EXCEPT AS EXPRESSLY SET FORTH IN THIS AGREEMENT, NEITHER RECIPIENT NOR ANY CONTRIBUTORS SHALL HAVE ANY LIABILITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR

CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST PROFITS), HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OR DISTRIBUTION OF THE PROGRAM OR THE EXERCISE OF ANY RIGHTS GRANTED HEREUNDER, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

7. GENERAL

If any provision of this Agreement is invalid or unenforceable under applicable law, it shall not affect the validity or enforceability of the remainder of the terms of this Agreement, and without further action by the parties hereto, such provision shall be reformed to the minimum extent necessary to make such provision valid and enforceable.

If Recipient institutes patent litigation against a Contributor with respect to a patent applicable to software (including a cross-claim or counterclaim in a lawsuit), then any patent licenses granted by that Contributor to such Recipient under this Agreement shall terminate as of the date such litigation is filed. In addition, if Recipient institutes patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Program itself (excluding combinations of the Program with other software or hardware) infringes such Recipient's patent(s), then such Recipient's rights granted under Section 2(b) shall terminate as of the date such litigation is filed.

All Recipient's rights under this Agreement shall terminate if it fails to comply with any of the material terms or conditions of this Agreement and does not cure such failure in a reasonable period of time after becoming aware of such noncompliance. If all Recipient's rights under this Agreement terminate, Recipient agrees to cease use and distribution of the Program as soon as reasonably practicable. However, Recipient's obligations under this Agreement and any licenses granted by Recipient relating to the Program shall continue and survive.

Everyone is permitted to copy and distribute copies of this Agreement, but in order to avoid inconsistency the Agreement is copyrighted and may only be modified in the following manner. The Agreement Steward reserves the right to publish new versions (including revisions) of this Agreement from time to time. No one other than the Agreement Steward has the right to modify this Agreement. IBM is the initial Agreement Steward. IBM may assign the responsibility to serve as the Agreement Steward to a suitable separate entity. Each new version of the Agreement will be given a distinguishing version number. The Program (including Contributions) may always be distributed subject to the version of the Agreement under which it was received. In addition, after a new version of the Agreement is published, Contributor may elect to distribute the Program (including its Contributions) under the new version. Except as expressly stated in Sections 2(a) and 2(b) above, Recipient receives no rights or licenses to the intellectual property of any Contributor under this Agreement, whether expressly, by implication, estoppel or otherwise. All rights in the Program not expressly granted under this Agreement are reserved.

This Agreement is governed by the laws of the State of New York and the intellectual property laws of the United States of America. No party to this Agreement will bring a

legal action under this Agreement more than one year after the cause of action arose. Each party waives its rights to a jury trial in any resulting litigation.

SPECIAL EXCEPTION FOR LZMA COMPRESSION MODULE

Igor Pavlov and Amir Szekely, the authors of the LZMA compression module for NSIS, expressly permit you to statically or dynamically link your code (or bind by name) to the files from the LZMA compression module for NSIS without subjecting your linked code to the terms of the Common Public license version 1.0. Any modifications or additions to files from the LZMA compression module for NSIS, however, are subject to the terms of the Common Public License version 1.0.

Openvswitch

Version 2.1.2

Copyright © 2014 Open vSwitch

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at:

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

Py2exe

Version 0.6.9

Copyright © 2000-2008 Thomas Heller, Mark Hammond, Jimmy Retzlaff

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Pyserial

Version 2.7

Copyright © 2013 Python Software Foundation

PYTHON SOFTWARE FOUNDATION LICENSE VERSION 2

1. This LICENSE AGREEMENT is between the Python Software Foundation ("PSF"), and the Individual or Organization ("Licensee") accessing and otherwise using this software ("Python") in source or binary form and

its associated documentation.

2. Subject to the terms and conditions of this License Agreement, PSF hereby grants Licensee a nonexclusive, royalty-free, world-wide license to reproduce, analyze, test, perform and/or display publicly, prepare derivative works, distribute, and otherwise use Python alone or in any derivative version, provided, however, that PSF's License Agreement and PSF's notice of copyright, i.e., "Copyright (c) 2001, 2002, 2003, 2004, 2005, 2006 Python Software Foundation; All Rights Reserved" are retained in Python alone or in any derivative version

prepared by Licensee.

3. In the event Licensee prepares a derivative work that is based on or incorporates Python or any part thereof, and wants to make the derivative work available to others as provided herein, then Licensee hereby agrees to include in any such work a brief summary of the changes made to Python.

4. PSF is making Python available to Licensee on an "AS IS" basis. PSF MAKES NO REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED. BY WAY OF EXAMPLE, BUT NOT LIMITATION, PSF MAKES NO AND DISCLAIMS ANY REPRESENTATION OR WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE OR THAT THE USE OF PYTHON WILL NOT

INFRINGE ANY THIRD PARTY RIGHTS.

5. PSF SHALL NOT BE LIABLE TO LICENSEE OR ANY OTHER USERS OF PYTHON FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR LOSS AS A RESULT OF MODIFYING, DISTRIBUTING, OR OTHERWISE USING PYTHON, OR ANY DERIVATIVE THEREOF, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.

6. This License Agreement will automatically terminate upon a material breach of its terms and conditions.

7. Nothing in this License Agreement shall be deemed to create any relationship of agency, partnership, or joint venture between PSF and Licensee. This License Agreement does not grant permission to use PSF trademarks or trade name in a trademark sense to endorse or promote products or services of Licensee, or any third party.

8. By copying, installing or otherwise using Python, Licensee agrees to be bound by the terms and conditions of this License Agreement.

BEOPEN.COM LICENSE AGREEMENT FOR PYTHON 2.0

BEOPEN PYTHON OPEN SOURCE LICENSE AGREEMENT VERSION 1

1. This LICENSE AGREEMENT is between BeOpen.com ("BeOpen"), having an office at 160 Saratoga Avenue, Santa Clara, CA 95051, and the Individual or Organization ("Licensee") accessing and otherwise using this software in source or binary form and its associated documentation ("the Software").
2. Subject to the terms and conditions of this BeOpen Python License Agreement, BeOpen hereby grants Licensee a non-exclusive, royalty-free, world-wide license to reproduce, analyze, test, perform and/or display publicly, prepare derivative works, distribute, and otherwise use the Software alone or in any derivative version, provided, however, that the BeOpen Python License is retained in the Software, alone or in any derivative version prepared by Licensee.
3. BeOpen is making the Software available to Licensee on an "AS IS" basis. BEOPEN MAKES NO REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED. BY WAY OF EXAMPLE, BUT NOT LIMITATION, BEOPEN MAKES NO AND DISCLAIMS ANY REPRESENTATION OR WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE OR THAT THE USE OF THE SOFTWARE WILL NOT INFRINGE ANY THIRD PARTY RIGHTS.
4. BEOPEN SHALL NOT BE LIABLE TO LICENSEE OR ANY OTHER USERS OF THE SOFTWARE FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR LOSS AS A RESULT OF USING, MODIFYING OR DISTRIBUTING THE SOFTWARE, OR ANY DERIVATIVE THEREOF, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.
5. This License Agreement will automatically terminate upon a material breach of its terms and conditions.
6. This License Agreement shall be governed by and interpreted in all respects by the law of the State of California, excluding conflict of law provisions. Nothing in this License Agreement shall be deemed to create any relationship of agency, partnership, or joint venture between BeOpen and Licensee. This License Agreement does not grant permission to use BeOpen trademarks or trade names in a trademark sense to endorse or promote products or services of Licensee, or any third party. As an exception, the "BeOpen Python" logos available at <http://www.pythonlabs.com/logos.html> may be used according to the permissions granted on that web page.
7. By copying, installing or otherwise using the software, Licensee agrees to be bound by the terms and conditions of this License Agreement.

Python-daemon

Version 1.6.5

Copyright © 2010 Python Software Foundation

PYTHON SOFTWARE FOUNDATION LICENSE VERSION 2

1. This LICENSE AGREEMENT is between the Python Software Foundation ("PSF"), and the Individual or Organization ("Licensee") accessing and otherwise using this software ("Python") in source or binary form and its associated documentation.
2. Subject to the terms and conditions of this License Agreement, PSF hereby grants Licensee a nonexclusive, royalty-free, world-wide license to reproduce, analyze, test, perform and/or display publicly, prepare derivative works, distribute, and otherwise use Python alone or in any derivative version, provided, however, that PSF's License Agreement and PSF's notice of copyright, i.e., "Copyright (c) 2001, 2002, 2003, 2004, 2005, 2006 Python Software Foundation; All Rights Reserved" are retained in Python alone or in any derivative version prepared by Licensee.
3. In the event Licensee prepares a derivative work that is based on or incorporates Python or any part thereof, and wants to make the derivative work available to others as provided herein, then Licensee hereby agrees to include in any such work a brief summary of the changes made to Python.
4. PSF is making Python available to Licensee on an "AS IS" basis. PSF MAKES NO REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED. BY WAY OF EXAMPLE, BUT NOT LIMITATION, PSF MAKES NO AND DISCLAIMS ANY REPRESENTATION OR WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE OR THAT THE USE OF PYTHON WILL NOT INFRINGE ANY THIRD PARTY RIGHTS.
5. PSF SHALL NOT BE LIABLE TO LICENSEE OR ANY OTHER USERS OF PYTHON FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR LOSS AS A RESULT OF MODIFYING, DISTRIBUTING, OR OTHERWISE USING PYTHON, OR ANY DERIVATIVE THEREOF, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.
6. This License Agreement will automatically terminate upon a material breach of its terms and conditions.
7. Nothing in this License Agreement shall be deemed to create any relationship of agency, partnership, or joint venture between PSF and Licensee. This License Agreement does not grant permission to use PSF trademarks or trade name in a trademark sense to endorse or promote products or services of Licensee, or any third party.
8. By copying, installing or otherwise using Python, Licensee agrees to be bound by the terms and conditions of this License Agreement.

BEOPEN.COM LICENSE AGREEMENT FOR PYTHON 2.0

BEOPEN PYTHON OPEN SOURCE LICENSE AGREEMENT VERSION 1

1. This LICENSE AGREEMENT is between BeOpen.com ("BeOpen"), having an office at 160 Saratoga Avenue, Santa Clara, CA 95051, and the Individual or Organization ("Licensee") accessing and otherwise using this software in source or binary form and its associated documentation ("the Software").
2. Subject to the terms and conditions of this BeOpen Python License Agreement, BeOpen hereby grants Licensee a non-exclusive, royalty-free, world-wide license to

reproduce, analyze, test, perform and/or display publicly, prepare derivative works, distribute, and otherwise use the Software alone or in any derivative version, provided, however, that the BeOpen Python License is retained in the Software, alone or in any derivative version prepared by Licensee.

3. BeOpen is making the Software available to Licensee on an "AS IS" basis. BEOPEN MAKES NO REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED. BY WAY OF EXAMPLE, BUT NOT LIMITATION, BEOPEN MAKES NO AND DISCLAIMS ANY REPRESENTATION OR WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE OR THAT THE USE OF THE SOFTWARE WILL NOT INFRINGE ANY THIRD PARTY RIGHTS.

4. BEOPEN SHALL NOT BE LIABLE TO LICENSEE OR ANY OTHER USERS OF THE SOFTWARE FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR LOSS AS A RESULT OF USING, MODIFYING OR DISTRIBUTING THE SOFTWARE, OR ANY DERIVATIVE THEREOF, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.

5. This License Agreement will automatically terminate upon a material breach of its terms and conditions.

6. This License Agreement shall be governed by and interpreted in all respects by the law of the State of California, excluding conflict of law provisions. Nothing in this License Agreement shall be deemed to create any relationship of agency, partnership, or joint venture between BeOpen and Licensee. This License Agreement does not grant permission to use BeOpen trademarks or trade names in a trademark sense to endorse or promote products or services of Licensee, or any third party. As an exception, the "BeOpen Python" logos available at <http://www.pythonlabs.com/logos.html> may be used according to the permissions granted on that web page.

7. By copying, installing or otherwise using the software, Licensee agrees to be bound by the terms and conditions of this License Agreement.

Python-lockfile

Version 0.9.1

Copyright © 2013 Python Software Foundation

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR

PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Pyutmp

Version 0.2.1

Copyright © 2008-2010 Brian M. Clapper.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- * Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- * Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- * Neither the name "clapper.org" nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Wxpython

Version 2.9

Copyright © 2011 Python Software Foundation

WXWINDOWS LIBRARY LICENCE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Library General Public Licence as published by the Free Software Foundation; either version 2 of the Licence, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Library General Public Licence for more details.

You should have received a copy of the GNU Library General Public Licence along with this software, usually in a file named COPYING.LIB. If not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

EXCEPTION NOTICE

1. As a special exception, the copyright holders of this library give permission for additional uses of the text contained in this release of the library as licenced under the wxWindows Library Licence, applying either version 3.1 of the Licence, or (at your option) any later version of the Licence as published by the copyright holders of version 3.1 of the Licence document.
2. The exception is that you may use, copy, link, modify and distribute under your own terms, binary object code versions of works based on the Library.
3. If you copy code from files distributed under the terms of the GNU General Public Licence or the GNU Library General Public Licence into a copy of this library, as this licence permits, the exception does not apply to the code that you add in this way. To avoid misleading anyone as to the status of such modified files, you must delete this exception notice from such code and/or adjust the licensing conditions notice accordingly.
4. If you write modifications of your own for this library, it is your choice whether to permit this exception to apply to your modifications. If you do not wish that, you must delete the exception notice from such code and/or adjust the licensing conditions notice accordingly.

