



# **NGFW Security Management Center Appliance**

**7.1.9**

**Release Notes**

## Contents

- [About this release](#) on page 2
- [Build number and checksums](#) on page 2
- [System requirements on virtualization platforms](#) on page 3
- [Compatibility](#) on page 4
- [New features](#) on page 4
- [Enhancements](#) on page 5
- [Security updates](#) on page 7
- [Resolved and known issues](#) on page 7
- [Install the SMC Appliance](#) on page 7
- [Upgrade the SMC Appliance](#) on page 8
- [Find product documentation](#) on page 9

# About this release

This document contains important information about this software release for the Forcepoint NGFW Security Management Center Appliance (SMC Appliance). We strongly recommend that you read the entire document.

The SMC Appliance ships with pre-installed Forcepoint NGFW Security Management Center (SMC) software. The pre-installed SMC includes a Management Server and a Log Server. You can alternatively install the SMC Appliance software on a virtualization platform.



### Note

The SMC Appliance does not support high-availability for the Management Server or the Log Server.

## Upgrade deadline

Without installing the separate certificate update patch that is described in the [12281](#) Knowledge Base Article, this update can only be installed before 21st of January 2026 due to the expiration of the current update certificate. If you cannot install this update before 21st of January 2026, install the patch that is described in the [12281](#) Knowledge Base Article before that date to update only update certificates of your current installation. Otherwise, SMC Appliance upgrades or patches cannot be successfully installed after that date.

# Build number and checksums

The build number for SMC 7.1.9 is 11443. This release contains Dynamic Update package 1946.

Use checksums to make sure that files downloaded correctly.

### 7.1.9P001.sap

```
SHA256SUM:
0cdb4a5f8ebcc73a21f5c4397543fe82135a0b1ee1eba8eb8d9710c68c18ce8f

SHA512SUM:
24f7e4947236eb3bb66d10101003f036
793a35f4ab2809a1737a75daf27de22c
0f6ff2abede9e706018e69342d3231b7
9289ba38350a2f84806917ce3c14c237
```

### 7.1.9U001.sap

```
SHA256SUM:
4bcfe901d20c605da49ffdb62cb7c1f8b09dfdb036e478f762b1dedccd54425a

SHA512SUM:
20574891fd251e60427841b3f78204d4
9cfa1de2fc62335f87bede2585a76ada
2fbe6322aad25de8072e3ff89a152e71
148e9f5c8a713f6525097172aa2ca247
```

### smca-7.1.9-11443.x86\_64.iso

```
SHA256SUM:
feb3ee195880db8f1d29dc6cd2403ccfea3dbbbabf85dae3d6d19c0b1b01a256

SHA512SUM:
19f8f3d42b266a4793ef81643059e04f
42f0cdf4160936940b828a89b93e1af5
445b70779762209d1c7df43d3bba0255
7321a83d21294a71177254bf004e9340
```

## System requirements on virtualization platforms

As an alternative to using the SMC Appliance software on the pre-installed Forcepoint appliance, you can install the SMC Appliance software on a virtualization platform.



#### CAUTION

To protect the privacy of your data, we recommend installing the NGFW Engines, SMC components, or SMC Appliance on a hypervisor that does not host any other virtual machines.

Component	Requirement
Hypervisor	VMware ESXi version 6.0 or higher
Memory	16 GB RAM
Virtual disk space	128 GB
Interfaces	At least one network interface

The .iso installation file that is used to install the SMC Appliance software on a virtualization platform is available only for major versions of the SMC Appliance. To install the maintenance version, first install the .iso for the major version, then upgrade to the maintenance version.

# Compatibility

SMC 7.1 can manage all compatible Forcepoint NGFW Engine versions up to and including version 7.1.



## Important

Some versions of Forcepoint NGFW have reached end-of-life status and no longer receive maintenance releases that contain security updates. Even though these Forcepoint NGFW versions might be compatible with the SMC, we recommend that you use a Long-Term Support version that is still supported. For more information about the Forcepoint NGFW lifecycle policy, see <https://support.forcepoint.com/ProductSupportLifeCycle>.

SMC 7.1 is all compatible with the Secure SD-WAN Engine versions up to and including version 7.1.

SMC 7.1 is compatible with Engine 6.8 or higher.

## New features

This release of the product includes these new features. For more information and configuration instructions, see the *Forcepoint Next Generation Firewall Product Guide* and the *Forcepoint Next Generation Firewall Installation Guide*.

### Forward traffic to specific tunnels or routers

By configuring the Forced Next Hop (FNH) option in the access rule you can now force forward traffic to a specific tunnel or router.

The advantage of using this option is that you can forward the matched traffic to a specific application that has the server behind a tunnel.

For more information, see *Configure Forced Next Hop routing* section in *Forcepoint Next Generation Firewall Product Guide*.

### SMC contact via FQDN

Support for using FQDN as the contact address to enable the engine to contact the SMC management server or log server. This can be beneficial when you run the SMC management server or log server in a cloud environment where managing long term public IP address is not feasible or is difficult.

For more information, see *Define Management Server or Log Server contact addresses*, and *Define contact address* sections in *Forcepoint Next Generation Firewall Product Guide*.

### Additional admin user authentication methods supported

The following admin user authentication methods are supported:

- OpenID Connect authentication by using an OpenID Connect provider.
- SAML authentication by using a SAML based identity provider.

For more information, see *Authenticate administrators using OpenID authentication method*, and *Authenticate administrators using SAML v2 authentication method* sections in *Forcepoint Next Generation Firewall Product Guide*.

## Improved SMC Domain Overview

The Domain Overview is updated to improve its scalability and usability to help users to easily navigate and find the domain information that they are looking for.

For more information, see *Log on to a Domain from the Domain Overview* section in *Forcepoint Next Generation Firewall Product Guide*.

## User Interface Themes

You can switch between light and dark theme for SMC.

For more information, see *Customize the Management Client layout* section in *Forcepoint Next Generation Firewall Product Guide*.

## DNS Sinkholing

You can now configure DNS sinkholing for UDP and TCP service elements. One of the scenarios where this feature can be useful is, when there is an infected machine in the internal network. It can be identified by using the DNS sinkholing.


For more information, see *Create custom service elements* section in *Forcepoint Next Generation Firewall Product Guide*.

# Enhancements

This release of the product includes these enhancements.

## Enhancements in SMC version 7.1.0

Enhancement	Description
BGP Monitoring Protocol (BMP) Configuration	<p>Support for BMP configuration options from the Dynamic Routing Editor. It is used to monitor BGP sessions and send the monitored data from BGP routers to the network management entities. Also, when configured the log events includes the information for the configured options, and which in turn helps to make correlation of BMP and engine logs easy for analytics.</p> <p>For more information, see <i>Create core elements for dynamic routing</i>, and <i>Enable BGP on the Engine, Engine Cluster, or Virtual Engine</i> sections in <i>Forcepoint Next Generation Firewall Product Guide</i>.</p>

Enhancement	Description
Improved Application Health Monitoring	<p>The Application Health Monitoring feature now comes with the following support:</p> <ul style="list-style-type: none"> <li>Enhanced engine monitoring and better support for non-TCP traffic, that is there is now support for applications that use UDP for data transport.</li> <li>Visibility into application health history and health status history of network applications.</li> <li>Better ISP link status monitoring.</li> <li>Application health status history.</li> </ul> <p>For more information, see <i>Application Health Monitoring Dashboard</i> section in <i>Forcepoint Next Generation Firewall Product Guide</i>.</p>
Improved SD-WAN algorithms and link selection logic	<p>The following updates have been done to provide for better user experience:</p> <ul style="list-style-type: none"> <li>Engine logic is updated to avoid too much packet loss before the traffic is sent to the better links.</li> <li>The QoS link value is tuned to make QoS link value selection feature to work as intended.</li> </ul> <p>Also, the <b>Default SD-WAN Link Balancing Preference</b> option is made available to allow you to set the preferences on how the traffic is balanced over the links for each engine.</p> <p>For more information, see <i>Create Link Usage Profile elements</i> section in <i>Forcepoint Next Generation Firewall Product Guide</i>.</p>
Tunnel interface now supports multiple IP addresses	It is now possible to add multiple IP addresses (that can be of types IPv4 and IPv6) for tunnel interfaces.
IPFIX forwarding	<p>When you export IPFIX information, the following new IPFIX Element IDs are now supported:</p> <ul style="list-style-type: none"> <li>EID 5 ipClassOfService</li> <li>EID 58 vlanId (source VLAN)</li> <li>EID 59 postVlanId (destination VLAN)</li> <li>EID 60 ipVersion</li> <li>EID 89 forwardingStatus</li> <li>EID 90 mplsVpnRouteDistinguisher</li> <li>EID 131 exporterIPv6Address</li> </ul> <div>  <p><b>Note</b></p> <ol style="list-style-type: none"> <li>EID 90 mplsVpnRouteDistinguisher is exported, only when BMP monitoring is configured for the engine that originates the log entries.</li> <li>The following IPFIX element IDs are only generated by engine version 7.1.0 or later: <ul style="list-style-type: none"> <li>EID 5 ipClassOfService</li> <li>EID 89 forwardingStatus</li> <li>EID 90 mplsVpnRouteDistinguisher</li> </ul> </li> </ol> </div>

# Security updates

---

For information about third-party packages and associated vulnerabilities included with SMC in this product release, see Knowledge Base article [11241](#).

# Resolved and known issues

---

For a list of resolved and known issues in this product release, see Knowledge Base article [4751](#).

# Install the SMC Appliance

---

Use these high-level steps to install the SMC Appliance.

For detailed information about installing the SMC Appliance and the NGFW Engines, see the *Forcepoint Next Generation Firewall Installation Guide*. All guides are available for download at <https://support.forcepoint.com/s/article/Documentation-Featured-Article>.

## Steps

- 1) Turn on the SMC Appliance.
- 2) Select the keyboard layout for accessing the SMC Appliance on the command line.
- 3) Accept the EULA.
- 4) Enter the account name and password.  
For credential requirements, see the *Forcepoint Next Generation Firewall Installation Guide*.
- 5) Make your security selections.
- 6) Complete the network interface and network setup fields.
- 7) Enter a host name for the Management Server and set DNS servers.
- 8) Select the time zone.
- 9) (Optional) Configure NTP settings.
- 10) After the SMC Appliance has restarted, install the Management Client from Forcepoint support or from P patch.  
As an alternative to installing the Management Client locally, you can use SMC Web Access to start and run the Management Client in a web browser. SMC Web Access is enabled by default for new installations of the SMC Appliance.

- 11) Import the licenses for all components.  
You can generate licenses at <https://stonesoftlicenses.forcepoint.com>.
- 12) Create the NGFW Engine elements, then install and configure the NGFW Engines.

## Upgrade the SMC Appliance

Use an upgrade patch to upgrade the SMC Appliance from a previous version to version 7.1.9.

There are two kinds of SMC Appliance patches:

- Hotfix patches include improvements and enhancements for the current SMC Appliance version. Hotfix patch files use the letter P as a separator between the version number and the patch number. Example: 7.1.1P001
- Upgrade patches upgrade the SMC Appliance to a new version.  
Upgrade patch files use the letter U as a separator between the version number and the patch number.  
Example: 7.1.1U001

We recommend checking the availability of SMC Appliance patches regularly, and installing the patches when they become available. For detailed information about installing SMC Appliance patches, see the *Forcepoint Next Generation Firewall Installation Guide*.

- SMC 7.1 requires an updated license.
  - If the automatic license update function is in use, the license is updated automatically.
  - If the automatic license update function is not in use, request a license upgrade on our website at <https://stonesoftlicenses.forcepoint.com>. Activate the new license using the Management Client before upgrading the software.
- The SMC Appliance must be upgraded before the NGFW Engines are upgraded to the same major version.
- You can upgrade from the following SMC versions; however, only the latest maintenance release and LTS versions are tested. Hence, It is recommended to upgrade to the latest LTS release of SMC, regardless of NGFW Engine versions being managed. For detailed information on how to upgrade SMC Appliance to a new version, see *Forcepoint Next Generation Firewall Installation Guide*.
  - 6.10.13 - 6.10.18
  - 7.1.1 - 7.1.8

For detailed information on how to upgrade the SMC Appliance from a version that is not listed above to a newer version, see Knowledge Base article [41318](#).

- If you configured SNMP for the SMC Appliance before upgrading to version 6.4.0 or higher, you must configure SNMP again.

You can upgrade the SMC Appliance using the Management Client or using the appliance maintenance and bug remediation (AMBR) patching utility on the command line of the SMC Appliance. For detailed information, see *Forcepoint Next Generation Firewall Product Guide*.



# Find product documentation

In the Forcepoint Customer Hub, you can find information about a released product, including product documentation, technical articles, and more.

You can get additional information and support for your product in the Forcepoint Customer Hub at <https://support.forcepoint.com>. There, you can access product documentation, release notes, Knowledge Base articles, downloads, cases, and contact information.

You might need to log on to access the Forcepoint Customer Hub. If you do not yet have credentials, create a customer account. To create a customer account, navigate to the Customer Hub Home page, and then click the **Create Account** link.

## Product documentation

Every Forcepoint product has a comprehensive set of documentation.

- *Forcepoint Next Generation Firewall Product Guide*
- Forcepoint Next Generation Firewall online Help



### Note

By default, the online Help is used from the Forcepoint help server. If you want to use the online Help from a local machine (for example, an intranet server or your own computer), see Knowledge Base article [10097](#).

- *Forcepoint Next Generation Firewall Installation Guide*

Other available documents include:

- *Forcepoint Next Generation Firewall Hardware Guide* for your model
- *Forcepoint NGFW Security Management Center Appliance Hardware Guide*
- *Forcepoint Next Generation Firewall Quick Start Guide*
- *Forcepoint NGFW Security Management Center Appliance Quick Start Guide*
- *Forcepoint NGFW SMC API User Guide*
- *Forcepoint VPN Client User Guide* for Windows or Mac
- *Forcepoint VPN Client Product Guide*
- *Forcepoint NGFW Manager and VPN Broker Product Guide*

